

## Steps for Assembly

1. Remove your normal plane blade from the plane and back the frog tension off as far as possible (Figure 1).
2. Place the insert knife bevel up with the large flat face down on the bed of the plane just behind the mouth (figure 2).
3. Place the holder over the top with the two pins lined up with the holes in the insert knife (figures 3, 4, 5).
4. Place the frog on top of the holder and tension as you would a normal plane blade (you may need to back the set screw out) (Figure 6).
5. Proceed to use your block plane as normal!

Figure 1



Figure 2



Figure 3



Figure 4



Figure 5



Figure 6



